


Lamp Current Sensor




Sensitivity Set Up


The sensitivity of the lamp current sensor can be set to four different levels by setting the DIL switch accessed on the side of the unit, setting as below,




Low Sensitivity



Medium Low Sensitivity



Medium High Sensitivity



High Sensitivity

Note:

The setting is dependant upon the type of fitting it is connected to, the position of the sensor coil and the DIL switch setting should be set as advised by ALC Lightng Controls.