


Installation Guide


Spine Bus Extension Socket



Fixing: 2 Number 20mm Long No.8 Screws Included

Wiring

Spine Bus Connection From Area Controller



Typical Application

The Spine Bus extenders are typically mounted in the Riser cupboard for the floors that are connected to an Area Controller sited on a different floor. These provide a connection point for the set up of the lighting on each separate floor.

